

2026/01/29

Technical Deepdive Advanced Diagnostics Hardware

Presentors/Authors:
Kurt Klauke

HORIBA

DELYCIOUS




Co-funded by
the European Union

The project is supported by the Clean Hydrogen Partnership and its members under the GA 101192075. Co-funded by the European Union. Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or the Clean Hydrogen Partnership. Neither the European Union nor the granting authority can be held responsible for them.


Introduction – System Concept

Goal: State of health analysis, recommend optimized operating conditions (no closed-loop control)




Introduction – System Concept

Goal: State of health analysis, recommend optimized operating conditions (no closed-loop control)




Introduction – System Concept

Goal: State of health analysis, recommend optimized operating conditions (no closed-loop control)



Introduction – System Concept


Goal: State of health analysis, recommend optimized operating conditions (no closed-loop control)



Raman Spectrometer

Gas Crossover - Indicator for Electrolyzer Health

- Hydrogen crossover to Oxygen Electrode
- Oxygen crossover to Hydrogen Electrode



Gas phase Raman spectroscopy

- Inline measurement developed by HORIBA
- Short measurement times between 1 s and 20 s
- Identification and quantification of H₂, N₂, O₂ and H₂O between < 1% and 100 %
- Measurement channels for anode and cathode outlets



D3.2
Lab-scale Raman

Electrochemical Impedance Spectroscopy

Essential tool for assigning degradation to cell components

The challenge – Transition from lab- to large-scale


- Low cell resistances in large-scale systems ($\text{m}\Omega$ - $\mu\Omega$ range)
- Maintain frequency bandwidth at high modulation currents
- Modulation independent of electrolyzer current supply

Features for large-scale tests

- Support for > 10 kA DC currents and 2 MW power
- Provision of sufficiently high modulation currents
- Parallel measurement of multiple cells or cell groups




D3.6
Lab-scale EIS




Electrochemical Impedance Spectroscopy



Lab-scale (Ω - $m\Omega$)




Electrochemical Impedance Spectroscopy



- Lab rule-of-thumb:
Modulate 5 % of DC current


Electrochemical Impedance Spectroscopy

Lab-scale (Ω - $m\Omega$)



- Lab rule-of-thumb:
Modulate 5 % of DC current

Large-scale ($m\Omega$ - $\mu\Omega$)



- Maintain frequency bandwidth at high modulation currents
- Frequency limit of most power supplies < 5 kHz
Modulation independent of PSU

Test benches

Lab-scale

PEM



Alkaline



SOEC

UNIVERSITY
OF TWENTE.



Adaptations to include:


- Lab-scale EIS (Sivonic)
- Raman Spectrometer Prototype (Horiba)

Large-scale

Alkaline



- 2 MW Horiba test bench installed at Fraunhofer IWES
- Electrolysis stack (Stargate Hydrogen)
- EMS system (Dumarey)
- Raman spectrometer (Horiba)
- EIS (Sivonic)




Thank you for your attention!

✉ Contact: kurt.klauke@horiba.com

🌐 [Delycious-project.eu](https://delycious-project.eu)

in [DELYCIOUS project](#)

HORIBA **DELYCIOUS**



The project is supported by the Clean Hydrogen Partnership and its members under the GA 101192075. Co-funded by the European Union. Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or the Clean Hydrogen Partnership. Neither the European Union nor the granting authority can be held responsible for them.

